



## CALL:

Used to answer and initiate calls.



## Redial:

Redials the last number dialed.



## Scroll:

To scroll through information. Also from idle screen, scroll down for missed calls.



## Soft Keys:

Pressing selects the function displayed above the key.



## Select:

To toggle and select features



## VOLUME:

Controls the speakerphone and ringer volume.



## MUTE:

Mutes and un-mutes an active call.

## BASIC PHONE FEATURES

**MAKE A CALL:** Dial the number from the keypad. To initiate the call, press the Call key or press Dial.

**ANSWER A CALL:** Press the Call key or press Answer.

**CALL HOLD:** Press Hold. To resume the call press Resume.

**DISCONNECT A CALL:** Press the Call key or press End Call.



# HOSTED PBX YEALINK CP920 STATIONS

## ADVANCED CALL HANDLING

**CALL PARK:** Call parks are virtual environments that exist to hold a call that is available to be retrieved from another station in the business. Once a call has been parked, you will be notified of the park queue number. To access that call, press Retrieve and dial the queue number provided and press Enter.

**3-WAY CONFERENCE:** With a live call established, press Confnc. Dial the 3rd party and press Send. After they answer, press Confnc.

**TRANSFER:** Press Trnsfer and dial a number (or extension).

Then either:

- A) Press Send and wait for the recipient to answer and introduce the call. Then press the Transfer key a 2nd time to complete the transfer. Or
- B) Press Send and wait for the ring back tone. Then press the Trnsfer key a 2nd time to complete the transfer.

**TRANSFER TO VOICEMAIL:** Press the Trnsfer, press Blind, dial the number 5, dial the extension and press Send to complete the transfer to voicemail.